Strain and composition effects on Raman vibrational modes of hexagonal GaP-Si-Si_{1-x}Ge_x core shell nanowires


Z. Azdad¹, M. De Luca¹, H. Ikaros T. Hauge², M.A. Verheijen², E. P. A. M. Bakkers², and I. Zardo¹

- ¹ Department of Physics, University of Basel, Basel, Switzerland
- ² Applied Physics, Photonics & Semiconductors Nanophysics,
- Eindhoven Univeristy of Technology, 5600 MB, Eindhoven, The Netherlands

Motivation


- Hexagonal Ge is predicted to have a direct bandgap. Combining Si and Ge in the hexagonal structure to form hexagonal SiGe alloys is expected to provide a direct bandgap semiconductor for sufficiently high Ge content.
- μ-Raman spectroscopy can provide information on the crystalline quality, strain field, and alloy composition of single GaP-Si-Si_{1-x}Ge_x core shell Nanowires (NW) in a spatially resolved manner.

Assessment of vibrational modes



- Polarization dependent measurements have revealed the characteristic modes of hexagonal phase (E_2^H, E_{2g}) for all the layers.
- We observed some additional modes in the X(YZ)X configuration located at 388 and 412 cm⁻¹ that have been possibly assigned to GaP/Si interface mode and SiGe surface mode.
- We report for the first time the E_{2g} mode of Germanium, located at 294.5 cm⁻¹ for 78% Ge.

Investigation of growth homogeneity




- Spatially resolved µ-Raman measurement revealed the existence of defected region which extend up to 0.5 µm from the gold droplet. These defects are manifested in the form of a mix domain where both hexagonal and cubic Si modes are observed.
- The NW's feature then high crystal quality, which is homogenous along the wire as witnessed by the constant intensity of GaP, Si, SiGe and Ge phonon modes.

Acknowledgements

We acknowledge for financial support the Swiss National Science Foundation research grant (Project Grant No. 200021_165784).


Sample description



Hexagonal GaP-Si-Si_{1-x}-SiGe_x core shell NW's were grown using metal-organic vapor phase epitaxy (MOVPE) [1]:

- First: A high quality GaP hexagonal core was grown.
- Second: A perfect hexagonal Si shell was epitaxially grown around the wire.
- Third: A second shell is then grown varying the Ge content.

Assessment of composition and strain



- Varying Ge in Si matrix influences the vibrational frequency of Si-Si, Si-Ge and Ge-Ge modes.
- Both Ge-Ge A_{1g} and E_{2g} modes show a linear trend with a positive slope with increasing Ge content.
- For Si modes, the trend is more complex probably because of the contribution of the Si-Si modes stemming from the Si inner shell and SiGe outer shell.
 The presence of strain can be assessed more reliably from the GaP core since there is no
- contribution from the compositional variation to the shift of the mode frequency.

 We observed a negligible shift in the frequency of GaP modes up to 60% Ge. Increasing the
- Ge% to 80%, we observe a down shift of all GaP optical modes of 1.3 cm⁻¹ in agreement with the presence of tensile strain.
- For 38% Ge content we observed a sudden red shift in the LO, TO and E_2^H modes of GaP. Correlation with cross sectional TEM suggests that this behavior might be related to the presence of multi core structure, with cores of different dimensions, and a highly defected SiGe shell.

Conclusions

- μ -Raman spectroscopy was used to investigate the phonon modes of single GaP-Si-Si $_{1-x}$ Ge $_x$ core-shell NWs.
- Polarization dependent measurements were employed in a spatially resolved manner to assess the NW crystal phases.
- We investigate the crystalline quality, the strain field, and the alloy composition along these technologically relevant NWs.

References

- [1] Håkon Ikaros T. Hauge, Sonia Conesa-Boj et al. Nano Lett. 17 (1), 85 (2017)
- [2] Zheng Wenli, and Li Tinghui, Journal of Semiconductors, 33(11), 112001 (2012)



